

# OKI®

# C5100



## User's Guide

*Okī, Network Solutions  
for a Global Society*

Every effort has been made to ensure that the information in this document is complete, accurate, and up-to-date. The manufacturer assumes no responsibility for the results of errors beyond its control. The manufacturer also cannot guarantee that changes in software and equipment made by other manufacturers and referred to in this Guide will not affect the applicability of the information in it. Mention of software products manufactured by other companies does not necessarily constitute endorsement by the manufacturer.

While all reasonable efforts have been made to make this document as accurate and helpful as possible, we make no warranty of any kind, expressed or implied, as to the accuracy or completeness of the information contained herein.

The most up-to-date drivers and manuals are available from the Oki Data website <http://www.okidata.com> and <http://my.okidata.com>.

Copyright © 2003. All rights reserved.



As an ENERGY STAR® Program Participant, the manufacturer has determined that this product meets the ENERGY STAR guidelines for energy efficiency.

This product complies with the requirements of the Council Directives 89/336/EEC (EMC) and 73/23/EEC (LVD) as amended where applicable on the approximation of the laws of the member states relating to electromagnetic compatibility and low voltage.

Oki and Microline are registered trademarks of Oki Electric Industry Company Ltd.

ENERGY STAR is a registered trademark of the United States Environmental Protection Agency.

Hewlett-Packard, HP, and LaserJet are registered trademarks of Hewlett-Packard Company.

Microsoft, MS-DOS and Windows are registered trademarks of Microsoft Corporation.

Apple, Macintosh and Mac OS are registered trademarks of Apple Computers Inc.

Other product names and brand names are registered trademarks or trademarks of their proprietors.

# Contents

<b>Introduction</b>	<b>6</b>
Printer Overview	7
Front View	7
Rear View	8
Changing the display language	10
<b>Media Recommendations</b>	<b>11</b>
Media Weight Designations	11
Media Types	12
Paper	12
Envelopes	13
Transparencies	13
Labels	14
Media: Tray 1 and Optional Tray 2	15
Media Sizes: Trays 1 & 2	15
Auto Switching	16
Media: Multi-Purpose Tray	16
Media Sizes: Multi-Purpose Tray	17
Top Exit (Face Down Stacker)	18
Rear Exit (Face Up Stacker)	18
Optional Duplex Unit	18
<b>Loading Paper</b>	<b>19</b>
Trays 1 and 2	19
Multi-Purpose (MP) Tray	23
<b>Using the Printer Driver</b>	<b>27</b>
Windows 98/Me/XP/NT 4.0	27
Windows 2000	42
<b>Color Printing</b>	<b>56</b>
General Information	56
Factors That Affect the Appearance of Printed Documents	56
Choosing a Color Matching Method	59
RGB or CMYK?	59
Matching Photographic Images	60
Matching Specific Colors (e.g., a Company logo): RGB only	60
Printing Vivid Colors: RGB Only	60
Color Matching	61
Color Matching Options	61
The Print Color Swatch Utility	64

<b>Menu Functions</b>	<b>65</b>
How To Make Changes in The Menus	65
For Example:	67
Summary of Menu Defaults	68
Printer Menu	72
<b>Replacing Consumables</b>	<b>86</b>
Toner Cartridge Replacement	87
Image Drum Replacement	94
Belt Unit Replacement	103
Fuser Replacement	108
<b>Options</b>	<b>113</b>
RAM Memory	113
Second Paper Tray	114
Duplex Unit	115
<b>Clearing Paper Jams</b>	<b>116</b>
Jam 382	117
Jam 381	120
Jam 372 and 380	126
Jam 370, 373 and 383	128
Jam 371	130
Jam 391 and 392	133
Jam 390	135
<b>Troubleshooting</b>	<b>137</b>
LCD messages	137
Problem solving	142
Paper feed problems	142
Paper jam has been cleared, but printer does not print	142
Problems printing from Windows	143
Cannot configure for USB connection	143
Cannot print	145
Application error or general protection fault is displayed	146
Printing is slow	146
Printer requests paper size change to continue printing	147
Problems with poor quality printing	147
Miscellaneous problems	150
The power is on, but the printer does not go online	150
Print processing does not start	150
Print processing cancels	150
Printer makes a strange noise	150
Printer takes a long time to start printing	151
Toner rubs off when you rub the printed surface	151
<b>Specifications</b>	<b>152</b>



**Utility Programs. . . . . 154**

- Overview . . . . .154
- Color Swatch Utility. . . . .154
  - General Information. . . . .154
  - installing the Color Swatch Utility . . . . .155
  - Opening the Color Swatch utility . . . . .155
  - Using the Color Swatch Utility . . . . .155
- PrintSuperVision Utility. . . . . 157
  - General Information. . . . .157
  - installing PrintSuper Vision. . . . .157
  - Features . . . . .157
  - Additional Information . . . . .158
- Network Printer Status Utility . . . . .158
  - installing The Network Printer Status Utility Manually . . . . .158
  - To Open The Network Printer Status Utility. . . . .158
  - Checking the Printer Status . . . . .160
- Oki LPR Utility . . . . . 161
  - How to Install . . . . .161
  - LPR Status box . . . . .161
  - Additional Information . . . . .162

# Introduction

Your new printer is designed with advanced features to give you clear, vibrant color printing and crisp black and white pages at high speed on a range of print media.

## **Features:**


- Up to 12 pages per minute in full color.
- Up to 20 pages per minute in black and white.
- 600 dpi (dots per inch) print resolution.
- Single Pass Color Digital LED technology.
- Hiper-C emulation.
- 10 Base-T and 100 Base-TX network connection.

## **Options:**

- Duplex Unit (Oki 42158401) for automatic two-sided printing (see page 115).
- Additional Memory (see page 113):
  - 64 MB (Oki 70043001)
  - 128 MB (Oki 70043101)
  - 256 MB (Oki 70043201).
- Second Paper Tray (Oki 42158501), capacity 530 sheets 20-lb. paper (see page 114).


# PRINTER OVERVIEW

## Front View



- 1 Output Stacker, face down**  
Standard printed copy delivery point. Holds up to 250 sheets of 20-lb. (75 g/m<sup>2</sup>) paper.
- 2 Operator Panel**  
Menu driven operator controls and LCD display panel (can be changed to show different languages: see page 10).
- 3 PaperTray**  
Standard paper tray. Holds up to 300 sheets of 20-lb. (75 g/m<sup>2</sup>) paper.
- 4 Multi-Purpose Tray**  
Used for feeding transparencies, heavier paper stocks, envelopes and other special media. Also for manual feeding of single sheets when required.

## Rear View



- 1** On/Off Switch
- 2** Socket for Power Cord
- 3** USB Interface
- 4** Network Interface
- 5** *Optional Duplex Unit*
- 6** **Rear Stacker** (face up), Capacity 100 sheets

When the rear paper stacker is folded down, paper exits the printer through the rear of the printer and is stacked face up. This is used for labels, heavy print media, envelopes and custom paper sizes. When used in conjunction with the Multi-Purpose Tray, the paper path through the printer is essentially straight. This avoids bending the print media around curves in the paper path and makes paper feeding more reliable.

## NOTES, CAUTIONS, ETC.

### NOTE

A note appears like this. A note provides additional information to supplement the main text which helps you to use and understand the product.

### CAUTION!

A caution appears like this. A caution provides additional information which, if ignored, may result in equipment malfunction or damage.


### WARNING!

*A warning appears like this. A warning provides additional information which, if ignored, may result in a risk of personal injury.*

### Important!

An important message appears like this. An important message provides supplemental information which can prevent potential problems.

# CHANGING THE DISPLAY LANGUAGE



1. Press **MENU +** repeatedly until you see

---

SYSTEM CONFIG MENU  
POWER SAVE DELAY TIME

---

2. Press **ENTER**.

3. Press **MENU +** repeatedly until you see

---

SYSTEM CONFIG MENU  
LANGUAGE

---

4. Press **ENTER**.

5. Press **MENU +** and/or **MENU -** repeatedly until you see the language you wish to select.
6. Press **ENTER** to select this language.
7. Press **ON LINE** to exit the menu and return the printer to standby.

# Media Recommendations

Your printer can handle a variety of print media, including a range of paper weights and sizes, transparencies, labels and envelopes. This section provides general advice on choice and use of media.

## CAUTION!

**Print media must be able to withstand 446°F (230°C) for 0.2 second.**

## MEDIA WEIGHT DESIGNATIONS

Weight Designation	Weight	Feed Tray	Duplexer?	Exit Tray
Light	16-19 lb. US Bond (60-71 g/m <sup>2</sup> )	Tray 1 Tray 2	No	Top <sup>a</sup> Rear <sup>b</sup>
Medium	20-27 lb. US Bond (75-101 g/m <sup>2</sup> )	Tray 1 Tray 2 MP Tray	Yes	Top Rear
Heavy	28-32 lb. US Bond (105-120 g/m <sup>2</sup> )	Tray 1 Tray 2 MP Tray	Yes (restricted to 28 lb. maximum)	Rear Only
Ultra Heavy	33-54 lb. US Bond (124-203 g/m <sup>2</sup> )	Tray 2 <sup>c</sup> MP Tray	No	Rear Only

- a. Face Down Stacker
- b. Face Up Stacker
- c. 47 lb. (177 g/m<sup>2</sup>) maximum for Tray 2

# MEDIA TYPES

## Paper

The best performance is obtained when using paper designed for use in copiers and laser printers. Suitable types include:


- Hammermill® Laser Printer Radiant White, 24 lb. US Bond (90 g/m<sup>2</sup>)
- Xerox® 4024, 20 lb. US Bond (75 g/m<sup>2</sup>)
- Oki® 52206101 Bright White Proofing Paper, 32 lb. US Bond (120 g/m<sup>2</sup>)

## Recommendations


- Check <http://my.okidata.com> for the latest information on recommended papers for your printer.
- Paper should be stored flat, away from moisture, direct sunlight and heat sources.
- **The use of heavily laid or textured paper will seriously affect the life of the image drum and give poor print quality.** Print quality can be improved by changing the media setting to 'Ultra Heavy.' However, this will reduce the output speed and prevent the use of the duplex option.
- *Avoid:*
  - Damp, damaged or curled paper.
  - Very smooth, shiny or glossy paper.
  - Heavily embossed letterhead paper, very rough paper or paper that has a large grain difference between the two sides.
  - Paper with perforations, cut-outs or ragged edges.
  - Carbon paper, recycled paper, NCR paper, photosensitive paper, pressure sensitive paper or thermal transfer paper.



## Envelopes



Yes




No

- Use only recommended envelopes (Oki 52206301 and 52206302: see “Selecting/Using OKI Print Media” in your *C5100 Handy Reference Guide* for more information).
- Envelopes should be stored flat and away from moisture, direct sunlight and heat sources.
- Don’t use envelopes with windows or metal clasps.
- Don’t use damp, damaged or curled envelopes.

### CAUTION

**Print media must be able to withstand 446°F (230°C) for 0.2 second.**

## Transparencies



- Use only recommended transparencies (3M CG3720, Oki 52205701).
- Avoid office transparencies designed for use by hand with marker pens. *These will melt in the fuser and cause damage.*

## Labels

- Avery 5161 White Laser Labels (letter size) work well with your printer. Check <http://my.okidata.com> for the latest information on media for your printer.
- Use only labels designed for use in color laser printers and photocopiers.

### CAUTION!

- **Labels should cover the entire carrier sheet.**
- **Carrier sheet or adhesive must not be exposed to any part of the printer**

# MEDIA: TRAY 1 AND OPTIONAL TRAY 2

## Media Sizes: Trays 1 & 2

Paper size	Feed		Exit	
	Tray 1	Tray 2	Top <sup>a</sup>	Rear <sup>b</sup>
Letter (8½ x 11")	S, D <sup>c</sup>	S, D	S, D	S, D
Legal-14 (8½ x 14")	S, D	S, D	S, D	S, D
Legal-13.5 (8½ x 13.5")	S, D	S, D	S, D	S, D
Legal-13 (8½ x 13")	S, D	S, D	S, D	S, D
Executive (7¼ x 10½")	S, D	S, D	S, D	S, D
A4 (210 x 297 mm)	S, D	S, D	S, D	S, D
A5 (145 x 210 mm)	S, D	S, D	S, D	S, D
A6 (105 x 148 mm)	S	Not Usable	Not Usable	S
B5 (182 x 257 mm)	S, D	S, D	S, D	S, D
Custom	S: min. 3.94 x 5.83" [100 x 148 mm], max. 8.5 x 14" [215.9 x 355.6 mm]	S: min. 3.94 x 8.27" [100 x 210 mm], max. 8.5 x 14" [215.9 x 355.6 mm]	S	Not Usable.

- Use the Top Exit (Face Down Stacker) only for paper up to 47 lb. US Bond (98 lb. Index, 177 g/m<sup>2</sup>).
- Switch to the Rear Exit (Face Up Stacker) when you are printing paper heavier than 47 lb. US Bond (98 lb. Index, 177 g/m<sup>2</sup>).
- S = Simplex; D = Duplex (printing on both sides)

## Auto Switching

If you have identical paper stock loaded in the Multi-Purpose Tray or the optional Second Paper Tray, you can have the printer automatically switch to the other tray when the current tray runs out of paper. This function is enabled in the Print Menu. (See page 72.)

## MEDIA: MULTI-PURPOSE TRAY

Use the Multi-Purpose (MP) Tray for printing card stock, labels, envelopes and transparencies. Or load a stack of letterhead stationery to switch to as needed.

- A stack of media about 3/8" (10 mm) high can be loaded into the MP Tray, equivalent to about 10 envelopes or 50 transparencies.
- Media should be loaded print side *up*, top edge facing into the printer.
- Generally, the rear exit (Face Up Stacker) is used with the MP Tray.

### Important!

The duplex unit can be used for paper only, at weights up to 28 lb. US Bond (105 g/m<sup>2</sup> metric, 58 lb. Index). Do not use the duplex (two-sided printing) function for labels, envelopes, transparencies, or paper heavier than 28 lb. US Bond.

## Media Sizes: Multi-Purpose Tray

Paper size	Feed MP Tray	Exit	
		Rear <sup>a</sup>	Top <sup>b</sup>
Letter (8½ x 11")	Yes	Yes	Yes
Legal-14 (8½ x 14")	Yes	Yes	Yes
Legal-13.5 (8½ x 13.5")	Yes	Yes	Yes
Legal-13 (8½ x 13")	Yes	Yes	Yes
Executive (7¼ x 10½")	Yes	Yes	Yes
A4 (210 x 297 mm)	Yes	Yes	Yes
A5 (145 x 210 mm)	Yes	Yes	Yes
B5 (182 x 257 mm)	Yes	Yes	Yes
Envelopes (COM-10)	Yes	Yes	No
Custom: min. 3.94 to 5.83" [100 x 148 mm]; max. 8½ x 14" [216 x 356 mm], or banner <sup>c</sup>	Yes	Yes	No

- Use the Rear Exit (Face Up Stacker) for heavy paper, transparencies, envelopes, and labels.
- Use the Top Exit (Face Down Stacker) only for paper up to 47 lb. US Bond (98 lb. Index, 177 g/m<sup>2</sup>).
- Banner specifications:
  - Length: up to 47" (1.2 m)
  - Width Range = 8¼ to 8½" (210 to 215.9 mm)
  - Weight Range = 28 to 34 lb. US Bond (105 to 128 g/m<sup>2</sup>)
  - Path = Rear Exit (Face Up Stacker) only
  - Feed one sheet at a time.

## TOP EXIT (FACE DOWN STACKER)

- Holds up to 250 sheets of 20-lb. US Bond (42 lb. Index, 75 g/m<sup>2</sup> metric) standard paper
- Handles paper stocks up to 47 lb. US Bond (98 lb. Index, 176 g/m<sup>2</sup> metric).
- Pages are printed in reading order (page 1 first; last page on top, facing down).

## REAR EXIT (FACE UP STACKER)

The face up stacker at the rear of the printer should be opened and the tray extension pulled out when required for use. In this condition paper will exit via this path, regardless of driver settings.

- The face up stacker can hold up to 100 sheets of 20-lb. US Bond (42 lb. Index, 75 g/m<sup>2</sup>) standard paper.
- Handles stocks up to 54 lb. US Bond (113 lb. Index, 113 lb. Index, 203 g/m<sup>2</sup> metric).
- Papers are printed face up: for multi-page documents, select reverse order printing in your application Print dialog box so that the stack is in correct order.

### NOTE

**Always use this stacker and the Multi-Purpose Tray for paper stocks heavier than 47 lb. US Bond (98 lb. Index, 176 g/m<sup>2</sup> metric).**

## OPTIONAL DUPLEX UNIT

This option provides automatic two-sided printing on the same range of paper sizes as optional Tray 2 (i.e. all Tray 1 sizes except A6), using paper from 20 to 28-lb. US Bond (42 to 58 lb. Index, 75 to 105 g/m<sup>2</sup> metric).

# Loading Paper

## TRAYS 1 AND 2

### NOTE


If you have the optional second paper tray installed:

- If you are printing from the 1st (upper) tray, you can pull out the 2nd (lower) tray and reload it while the printer is printing.
- If you are printing from the 2nd (lower) tray, *do not pull out the 1st (upper) tray while printing*. This will cause a paper jam.


1. Remove the paper tray from the printer.



2. Fan the paper to be loaded at the edges (1) and in the middle (2), then tap the edges of the stack on a flat surface to make it flush again (3).




3. Load paper print side down, making sure the rear stopper (1) and paper guides (2) are snug against the paper.





## NOTE

Load letterhead paper face *down*, with the top edge aimed towards the front of the printer.



4. Gently close the paper tray.



## NOTE

To prevent paper jams:


- Do not leave space between the paper and the guides and rear stopper.
- Do not overfill the paper tray. Capacity depends on the type of paper stock.
- Do not load damaged paper.
- Do not load paper of different sizes or types at the same time.
- Do not pull the paper tray out during printing (except as described above for the 2nd tray).

## MULTI-PURPOSE (MP) TRAY


### NOTE

The MP Tray will take a stack of media about 3/8" (10 mm) high, equivalent to about 10 envelopes or 50 transparencies. Do not exceed the 3/8" (10 mm) media stack height.


1. Open the MP Tray.



2. Press down on the loading platform.



3. Load the print media and adjust the guides (1) to the size media being used.



- Letterhead stationery:
  - For single-sided printing, load with pre-printed side *up* and the top edge *into* the printer.
  - For two-sided (duplex) printing, load with pre-printed side *down* and top edge *away from* the printer. (Optional duplex unit must be installed.)
- Envelopes: load print side up (flap down) with top edge to the left and short edge into the printer. Do not select duplex printing on envelopes.

4. Press the blue tray latch (1) toward the paper stack to lift the paper platform into the feed position.



# Using the Printer Driver

The Windows printer driver contains settings for many of the same items as are found in the operator panel menus. Where items in the printer driver are the same as those in the operator panel menus, and you print documents from Windows, *the settings in the Windows printer driver will override those items in the operator panel menus.*

## WINDOWS 98/Me/XP/NT 4.0

### NOTE

**The illustrations in this section show the Windows Me Operating System. The other Windows operating systems may appear slightly different, but the principles are the same.**


- N-up Printing: multiple pages on one sheet (see page 28)
- Custom Page Sizes (see page 29)
- Selecting Print Resolution (see page 32)
- Duplex Printing (see page 34)
- Watermarks (see page 38)
- Collating (see page 40)
- Printing Posters (see page 41)

### NOTE

**Most applications allow the printer properties to be accessed from within the document print dialog box.**

## N-Up Printing (Printing Multiple Pages on One Sheet) 98 / Me / XP / NT 4.0

1. Open the file in your application and select **File** → **Print**.
2. In the **Print** dialog box, select your printer, then:
  - a. Windows 98/Me/NT4.0: click **Properties**.
  - b. Windows XP: click **Preferences**.
3. On the **Setup** tab, under **Finishing Mode** (1), select the required number of pages per sheet in the drop-down list. To set additional parameters, click **Options** (2), then make your selections and click **OK**.



4. Click **OK**.
5. Windows 98/Me/NT4.0: click **OK**.  
Windows XP: click **Print**.



## Printing Custom Page Sizes

### 98 / Me / XP / NT 4.0

Custom page sizes can be printed from Tray 1, Tray 2 or the Multi-Purpose (MP) Tray, one-sided printing only, rear exit only.

#### Tray 1 and Tray 2 Custom Size Range

- minimum 3.94" x 5.83" [100 x 148 mm]
- maximum 8½" x 14" [215.9 x 355.6 mm].

#### MP Tray Custom Size Range

- minimum 3.94" to 5.83" [100 x 148 mm]
- maximum 8½" x 14" [216 x 356 mm]

or banners from 8¼" to 8½" (210 to 215.9 mm) wide by up to 47¼" (1.2 m) long. Banners must be fed one sheet at a time.

### NOTE


Up to 32 custom page sizes can be defined.

1. Make sure the rear exit path is open:



2. Load the custom size paper in the tray of your choice.
3. Open the file in your application and select **File** → **Print**.

4. In the **Print** dialog box, select your printer, then:
  - a. Windows 98/Me/NT4.0: click **Properties**.
  - b. Windows XP: click **Preferences**.
5. On the **Setup** tab, under **Media**, select **User Defined Size** from the bottom of the **Size** drop-down list, or select a custom size you have already defined (see “Creating and Saving Custom Page Sizes” on page 31). Define the custom size in the dialog box which appears, then click **OK**.



## NOTE

You may see a Warning dialog box indicating a conflict. If you do, click **OK** and the driver will automatically make the needed changes to correct for the conflict.

6. Select the tray you will be using in the **Source** drop-down list under **Media**, then click **OK**.
7. Windows 98/Me/NT4.0: click **OK**.  
Windows XP: click **Print**.

## Creating and Saving Custom Page Sizes

### 98 / Me / XP / NT 4.0

1. Click **Start** → **Settings** → **Printers** [**Printers and Faxes** for XP].
2. Right click the C5100 printer icon, then:
  - a. Windows 98/Me: select **Properties**, then click the **Printer Properties** tab.
  - b. Windows XP: select **Properties**, then click **Printing Preference**.
  - c. Windows NT 4.0: select **Document Defaults**.
3. On the **Setup** tab, click **Paper Feed Options**.
4. Click **Custom Size**.
5. For each size, enter a name, width and height, then click **Add**.
6. When done, click **OK**.
7. Click **OK** three more times.

## Changing the Resolution for A Print Job

### 98 / Me / XP / NT 4.0

#### NOTE


These instructions explain how to change the settings as you are printing a job. If you wish to change the settings to apply to all jobs (default settings):

- Click Start → Settings → Printers [Printers and Faxes for XP].
- Right click the C5100 printer icon, then:
  - a. Windows 98/Me: select Properties, then click the Printer Properties tab.
  - b. Windows XP: select Properties, then click Printing Preference.
  - c. Windows NT 4.0: select Document Defaults.
- Follow steps 3, etc., below. Note that the screen for setting defaults will have more tabs.

1. Open the file in your application and select **File** → **Print**.
2. In the **Print** dialog box, select your printer, then:
  - a. Windows 98/Me/NT4.0: click **Properties**.
  - b. Windows XP: click **Preferences**.

3. On the **Job Options** tab, select the required printing resolution under **Quality**:

- **Fine** = high resolution, slower speed: choose this one for optimum results when printing graphics.
- **Normal** = medium resolution, medium speed: the default.
- **Fast** = low resolution, fast speed: choose this one for drafts or documents without graphics.



4. Select **Toner Saving** if appropriate.

5. Click **OK**

6. Windows 98/Me/NT4.0: click **OK**.  
Windows XP: click **Print**.

## Duplex Printing (Printing on Both Sides of The Paper) 98 / Me / XP / NT 4.0

### NOTE

The optional duplex unit must be installed in the printer and enabled before duplex printing can be carried out.

- Standard paper sizes only.
- Paper weight range 20 to 28 lb. US Bond (75 to 105 g/m<sup>2</sup>).
- Paper must be loaded print side *up*.
- Any tray (Tray 1, optional Tray 2, MP tray) can be used for duplex printing.


### NOTE

These instructions explain how to change the settings as you are printing a job. If you wish to change the settings to apply to all jobs:

- Click Start → Settings → Printers [Printers and Faxes for XP].
- Right click the C5100 printer icon, then:
  - a. Windows 98/Me: select Properties, then click the Printer Properties tab.
  - b. Windows XP: select Properties, then click Printing Preference.
  - c. Windows NT 4.0: select Document Defaults.
- Follow steps 3, etc., below. Note that the screen for setting defaults will have more tabs.

1. Open the file in your application and select **File** → **Print**.
2. In the **Print** dialog box, select your printer, then:
  - a. Windows 98/Me/NT4.0: click **Properties**.
  - b. Windows XP: click **Preferences**

3. On the **Setup** tab, under **2-Sided Printing**, select **Long Edge** or **Short Edge**.



4. Click **OK**.
5. Windows 98/Me/NT4.0: click **OK**.  
Windows XP: click **Print**.

## Printing Booklets

### 98 / Me / XP / NT 4.0


#### NOTES

- You must have the duplex unit installed and enabled in order to print booklets.
- Not available on some network connections: see the Help file.
- Some software applications may not support booklet printing.
- The right-to-left setting allows a booklet to be printed for right to left reading, which is used in some languages.

1. Open the file in your application and select **File** → **Print**.
2. In the **Print** dialog box, select your printer, then:
  - a. Windows 98/Me/NT4.0: click **Properties**.
  - b. Windows XP: click **Preferences**.



3. On the **Setup** tab, under **Finishing Mode**, select **Booklet** in the drop-down list.




4. Click **Options**, enter your settings, and click **OK**.
5. Click **OK**.
6. Windows 98/Me/NT4.0: click **OK**.  
Windows XP: click **Print**.

## Printing Watermarks

### 98 / Me / XP / NT 4.0

1. Open the file in your application and select **File** → **Print**.
2. In the **Print** dialog box, select your printer, then:
  - a. Windows 98/Me/NT4.0: click **Properties**.
  - b. Windows XP: click **Preferences**.
3. On the **Job Options** tab, click **Watermark**.



4. Select a name from the **Watermark** list or click New to set up a new watermark.

## NOTE

To create a new watermark or edit an existing watermark:

- Click the **New or Edit** button.
- Enter the text for the watermark and select the font, size, angle, etc., to be used.
- Click **OK**.

*The new watermark appears in the Watermark list.*


5. If you wish to print the watermark only on the first page of the document, select **First Page only**.
6. Click **OK** twice.
7. Windows 98/Me/NT4.0: click **OK**.  
Windows XP: click **Print**.

## Collating

### 98 / Me / XP / NT 4.0

The following instructions explain how to select collating using the printer driver.

1. Open the file in your application and select **File** → **Print**.
2. In the **Print** dialog box, select your printer, then:
  - a. Windows 98/Me/NT4.0: click **Properties**.
  - b. Windows XP: click **Preferences**.
3. On the **Job Options** tab, under **Job Type**, enter the number of copies required and select **Collate**.




4. Click **OK**.
5. Windows 98/Me/NT4.0: click **OK**.  
Windows XP: click **Print**.

## Printing Posters

### 98 / Me / XP / NT 4.0

This option allows you to configure and print posters by breaking up the document page into multiple pieces which print enlarged on separate sheets. Then the separate sheets are combined to produce a poster.

1. Open the file in your application and select **File** → **Print**.
2. In the **Print** dialog box, select your printer, then:
  - a. Windows 98/Me/NT4.0: click **Properties**.
  - b. Windows XP: click **Preferences**.
3. On the **Setup** tab, under **Finishing Mode**, select **PosterPrint**.



4. Click **Options...** and enter the configuration details (Note: an overlap of at least 0.2 mm must be specified.), then click **OK**.
5. Click **OK**.
6. Windows 98/Me/NT4.0: click **OK**.  
Windows XP: click **Print**.

## WINDOWS 2000


- N-up Printing: multiple pages on one sheet (see page 43)
- Custom Page Sizes (see page 46)
- Selecting Print Resolution (see page 47)
- Duplex Printing (see page 49)
- Watermarks (see page 52)
- Collating (see page 54)
- Printing Posters (see page 55)

### NOTE

**Most applications allow the printer properties to be accessed from within the document print dialog box.**

## N-Up Printing (Printing Multiple Pages on One Sheet) 2000

1. Open the file in your application and select **File** → **Print**.
2. In the **Print** dialog box, select your printer.
3. On the **Setup** tab, under **Finishing Mode** (1), select the required number of pages per sheet in the drop-down list. To set additional parameters, click **Options** (2), then make your selections and click **OK**.



4. Click **Print**.

## Printing Custom Page Sizes 2000

Custom page sizes can be printed from Tray 1, Tray 2 or the Multi-Purpose (MP) Tray, one-sided printing only, rear exit only.

### Tray 1 and Tray 2 Custom Size Range

- minimum 3.94" x 5.83" [100 x 148 mm]
- maximum 8½" x 14" [215.9 x 355.6 mm].

### MP Tray Custom Size Range

- minimum 3.94" to 5.83" [100 x 148 mm]
- maximum 8½" x 14" [216 x 356 mm]

or banners from 8¼" to 8½" (210 to 215.9 mm) wide by up to 47¼" (1.2 m) long. Banners must be fed one sheet at a time.


1. Make sure the rear exit path is open:



2. Load the custom size paper in the tray of your choice.
3. Open the file in your application and select **File** → **Print**.
4. In the **Print** dialog box, select your printer.



5. On the **Setup** tab, under **Media**, select **User Defined Size** in the **Size** drop-down list. Define the custom size in the dialog box which appears, then click **OK**.



## NOTE

You may see a Warning dialog box indicating a conflict. If you do, click **OK** and the driver will automatically make the needed changes to correct for the conflict.

6. Select the tray you will be using in the **Source** drop-down list under **Media**, then click **OK**.
7. Click **Print**.

## Creating and Saving Custom Page Sizes 2000

### NOTE

Up to 32 custom page sizes can be defined.

1. Click **Start** → **Settings** → **Printers**.
2. Right click the C5100 printer icon, then select **Properties**.
3. Click **Printing Preferences**.
4. On the **Setup** tab, click **Paper Feed Options**.
5. Click **Custom Size**.
6. For each size, enter a name, width and height, then click **Add**.
7. When done, click **OK**.
8. Click **OK** three more times.

## Changing the Resolution for A Print Job 2000

### NOTE


These instructions explain how to change the settings as you are printing a job. If you wish to change the settings to apply to all jobs (default settings):

- Click **Start** → **Settings** → **Printers**.
- Right click the appropriate printer name, then select **Properties**.
- Click **Printing Preferences**.
- Follow steps 3, etc., below. Note that the **Properties** screen for setting defaults will have more tabs.

1. Open the file in your application and select **File** → **Print**.
2. In the **Print** dialog box, select your printer.

3. On the **Job Options** tab, select the required printing resolution under **Quality**:

- **Fine** = high resolution, slower speed: choose this one for optimum results when printing graphics.
- **Normal** = medium resolution, medium speed: the default.
- **Fast** = low resolution, fast speed: choose this one for drafts or documents without graphics.



4. Select **Toner Saving** if appropriate.

5. Click **Print**.

## Duplex Printing (Printing on Both Sides of The Paper) 2000

### NOTE

The optional duplex unit must be installed in the printer and enabled before duplex printing can be carried out.

- Standard paper sizes only.
- Paper weight range 20 to 28 lb. US Bond (75 to 105 g/m<sup>2</sup>).
- Paper must be loaded print side *up*.
- Any tray (Tray 1, optional Tray 2, MP tray) can be used for duplex printing.


### NOTE

These instructions explain how to change the settings as you are printing a job. If you wish to change the settings to apply to all jobs:

- Click **Start → Settings → Printers**.
- **Right click the appropriate printer name, then select Properties.**
- **Click Printing Preferences.**
- **Follow steps 3, etc., below. Note that the Properties screen for setting defaults will have more tabs.**

1. Open the file in your application and select **File → Print**.
2. In the **Print** dialog box, select your printer.

3. On the **Setup** tab, under **2-Sided Printing**, select **Long Edge** or **Short Edge**.




4. Click **Print**.

## Printing Booklets 2000

### NOTES

- You must have the duplex unit installed and enabled in order to print booklets.
- Not available on some network connections: see the Help file.
- Some software applications may not support booklet printing.
- The right-to-left setting allows a booklet to be printed for right to left reading, which is used in some languages.


1. Open the file in your application and select **File** → **Print**.
2. In the **Print** dialog box, select your printer.
3. On the **Setup** tab, under **Finishing Mode**, select **Booklet** in the drop-down list.



4. Click **Options**, enter your settings, and click **OK**.
5. Click **Print**.

## Printing Watermarks 2000

1. Open the file in your application and select **File** → **Print**.
2. In the **Print** dialog box, select your printer.
3. On the **Job Options** tab, click **Watermark**.



4. Select a name from the **Watermark** list or click **New** to set up a new watermark. When you're finished setting up the new watermark, click **OK**.



## NOTE

To create a new watermark or edit an existing watermark:

- Click the **New** or **Edit** button.
- Enter the text for the watermark and select the font, size, angle, etc., to be used.
- Click **OK**.


*The new watermark appears in the Watermark list.*

5. If you wish to print the watermark only on the first page of the document, select **First Page only**.
6. Click **OK**.
7. Click **Print**.

## Collating 2000

The following instructions explain how to select collating using the printer driver.

1. Open the file in your application and select **File** → **Print**.
2. In the **Print** dialog box, select your printer.
3. On the **Job Options** tab, under **Job Type**, enter the number of copies required and select **Collate**.




4. Click **Print**.

## Printing Posters 2000

This option allows you to configure and print posters by breaking up the document page into multiple pieces which print enlarged on separate sheets. Then the separate sheets are combined to produce a poster.

1. Open the file in your application and select **File** → **Print**.
2. In the **Print** dialog box, select your printer.
3. On the **Setup** tab, under **Finishing Mode**, select **PosterPrint** in the drop-down list.



4. Click **Options...** and enter the configuration details (Note: an overlap of at least 0.2 mm must be specified.), then click **OK**.
5. Click **Print**.

# Color Printing

The printer driver supplied with this printer provides several controls for changing the color output of your printer. For general use the Auto settings will suffice, providing reasonable default settings that will produce good results for most documents.

Many applications have their own color settings, and these may override the settings in the printer driver. Please refer to the documentation for your software application for details on how that particular program's color management functions.

## GENERAL INFORMATION

### Factors That Affect the Appearance of Printed Documents

If you wish to manually adjust the color settings in your printer driver, please be aware that *color reproduction is a complex topic, and there are many factors to take into consideration*. Some of the most important factors are listed below.

#### Differences between the Range of Colors a Monitor or Printer Can Reproduce

- Neither a printer nor a monitor is capable of reproducing the full range of colors visible to the human eye. Each device is restricted to a certain range of colors. In addition to this, a printer cannot reproduce all of the colors displayed on a monitor, and vice versa.
- Both devices use very different technologies to represent color. A monitor uses Red, Green and Blue (RGB) phosphors (or LCDs), a printer uses Cyan, Magenta, Yellow and Black (CMYK) toner or ink.
- A monitor can display very vivid colors such as intense reds and blues and these cannot be easily produced on any printer using toner or ink. Similarly, there are certain colors, (some yellows for example), that can be printed, but cannot be displayed accurately on a monitor. This disparity between monitors and printers is often the main reason that printed colors do not match the colors displayed on screen.

## Viewing conditions

A print can look very different under different lighting conditions. For example, the colors in a print may look different when viewed standing next to a sunlit window, compared to how they look under standard office fluorescent lighting.

## Printer driver color settings

The driver settings for Manual color can change the appearance of a print. There are several options available to help match the printed colors with those displayed on screen.

## Monitor settings

The brightness and contrast controls on your monitor can change how your document looks on-screen. Additionally, your monitor's color temperature influences how "warm" or "cool" the colors look.

### NOTE

**Several of the Color Matching options make reference to your monitor's Color Temperature. Many modern monitors allow the color temperature to be adjusted using the monitor's control panel.**

There are several settings found on a typical monitor:

- **5000k\***  
Warmest; yellowish lighting, typically used in graphics arts environments.
- **6500k**  
Cooler; approximates daylight conditions.
- **9300k**  
Cool; the default setting for many monitors and television sets.

\*k = degrees Kelvin, a measurement of temperature

## **How Your Software Application Displays Color**

Some graphics applications such as CorelDRAW® or Adobe® Photoshop® may display color differently from "office" applications such as Microsoft® Word. Please see your application's on-line help or user manual for more information.

## **Paper Type**

The type of paper used can also significantly affect the printed color. For example, a printout on recycled paper can look duller than one on specially formulated glossy paper.

## CHOOSING A COLOR MATCHING METHOD

There is no correct way to achieve a good match between the document displayed on your monitor, and its printed equivalent. There are many factors involved in achieving accurate and reproducible color.

The following guidelines may help in achieving good color output from your printer. There are several suggested methods, depending on the type of document you are printing.

### NOTE

**These suggestions are for guidance only. Your results may vary depending on the application from which you are printing. Some applications will override any color matching settings in the printer driver without warning.**

### RGB or CMYK?

The guidelines for choosing a color matching method makes distinctions between Red, Green, Blue (RGB) and Cyan, Magenta, Yellow, Black (CMYK).

Generally, most documents you print will be in RGB format. This is the most common, and if you do not know your document's color mode, assume that it is RGB.

Typically CMYK documents are only supported in professional Desktop Publishing and Graphics applications.

The driver and Color Swatch Utility supplied with your printer support only RGB. If you wish to use CMYK, you might be able to use the software application's Soft Proofing feature (see "RGB or CMYK" on page 60).

## Matching Photographic Images

### RGB only

Oki Color Matching is generally a good choice. Select a matching method appropriate to your monitor.

### RGB or CMYK

If you are printing photographic images from a graphics application such as Adobe Photoshop, you may be able to use Soft-Proofing to simulate the printed image on your monitor. To do this, you can use the ICC-Profiles provided by Oki, and then print using the ICC profiles as the Print Space (or Output space).

### Matching Specific Colors (e.g., a Company logo): RGB only

- Option 1: Select the sRGB setting on the Color tab in the driver.
- Option 2: Use the Color Swatch Utility provided on the Publications CD supplied with your printer to print out a chart of RGB swatches, then enter the desired RGB values in your application's color picker.

### Printing Vivid Colors: RGB Only

Use either the Monitor 6500k Vivid, sRGB or Digital Camera settings.



# COLOR MATCHING


## Color Matching Options

The Color Matching options in the driver can be used to help match your printed colors to the ones displayed on your monitor.


### NOTE

The driver's color options are only designed to work with RGB data.

The driver color matching options are found on the **Color** tab in the driver:



To set the color matching options manually, click **Manual Color**. The **Color** tab screen will change to:



Choose from the following options:

- **Monitor (6500k) Perceptual**  
Optimized for printing daylight photographs.
- **Monitor (6500k) Vivid**  
Optimized for printing bright colors. Good for office graphics.
- **Monitor (9300k)**  
Optimized for printing photographs when using a monitor with this color temperature.
- **Digital Camera**  
Optimized for printing photographs taken with a digital camera. This tends to produce prints with lighter and brighter colors. For some photographs, other settings may be better depending on the subjects and the conditions under which they were taken.
- **sRGB**  
Optimized for matching specific colors, such as a company logo color. The colors within the printer's color gamut are printed without any modification, and only colors that fall outside the printable colors are modified.

### **To Engage a Predefined Color Profile as The Color Matching Default:**

1. Click **Start** → **Settings** → **Printers** [**Printers and Faxes** in Windows XP].
2. Right-click the printer name and select **Properties**.
3. On the **Color Management** tab, select **Manual**.
4. Click **Add**.
5. Select the profile of your choice and click **Add**. Repeat this step for each profile you wish to add to the list box on the Color Management tab.
6. In the list box, highlight the profile you wish to use, then click **Set as Default**.
7. Click **OK**.

### **To Select A Manual Color Matching Option as The Default:**

1. Click **Start** → **Settings** → **Printers** [**Printers and Faxes** in Windows XP].
2. Right-click the printer name and:
  - a. Windows 98/Me: select **Properties**, then click **Printer Properties**.
  - b. Windows 2000/XP: select **Properties**, then click **Printing Preferences**.
  - c. Windows NT 4.0: select **Document Defaults**.
3. On the **Color** tab, click **Manual**.
4. Make your selections, then click **OK** twice.


## To Change the Color Matching Options for A Particular Print Job:

1. Open the file in your application and select **File** → **Print**.
2. In the **Print** dialog box, select your printer.
  - a. Windows 98/Me/NT4.0: click **Properties**.
  - b. Windows XP: click **Preferences**.
3. Click the **Color** tab, select **Manual Color** and make your changes, then go back to the **Print** dialog box and print the document.

## The Print Color Swatch Utility

For use with applications which allow you to set your own RGB values for colors.

The Color Swatch utility prints out charts of sample colors. Listed below each color are the corresponding RGB (Red, Green, Blue) values to use in your application to match that printed color:




For more information see page 154.

# Menu Functions

This section lists the menus accessed via the controls on the printer's operator panel and displayed in the LCD window.

Many of these settings can be overridden by settings in the Windows printer drivers. However, several of the driver settings can be left at "Printer Setting," which will then default to the settings entered in these printer menus

## HOW TO MAKE CHANGES IN THE MENUS



1. Press **+** to enter the menu mode.
2. Press **+/-** to scan through the available menus until the menu you wish to enter appears on the display.

### NOTE

The menus and their various listings will vary depending on which options you have installed on your printer.

3. Press **ENTER** to enter the menu.
4. Use **+/-** to move up and down through the items in the selected menu. When the item you want to change is displayed, press **ENTER** to edit that item.
5. Use **+/-** to move up and down through the available settings for this item.

6. When the setting you wish to use appears on the display, press **ENTER**.

*An asterisk (\*) appears next to the setting, and the setting flashes.*

7. To finish:

- a. If you are through making settings in the menu, press **ON LINE** to engage the setting and exit the menu.
- b. If you wish to make additional changes in the menu, press **BACK** to engage the setting.
  - To change another setting in the same menu, use **+/-** to move through the list of menu items to the one you wish to change, then follow steps 5 through 7.
  - To change the setting for an item in a different menu, press **BACK** again, then follow steps 2 through 7.

## For Example:

To change the time interval for the printer to wait before going into Power Save mode (default setting is 60 MIN):

1. Press **+** to enter the menu mode.
2. Press **+** and/or **-** repeatedly until you see

---

SYS CONFIG MENU

---

3. Press **ENTER** to go into the Sys Config Menu.

---

POW SAVE TIME  
60 MIN \*

---

4. Press **ENTER** to select the Power Save Time item.  
*The value on the second line of the display begins flashing.*

---

POW SAVE TIME  
60 MIN \*

---

5. Press **+** repeatedly until the interval (e.g., 240 MIN) you wish to select appears on the second line.

---

POW SAVE TIME  
240 MIN

---

6. Press **ENTER** to select the new setting:  
*An asterisk appears on the second line of the display.*

---

POW SAVE TIME  
240 MIN \*

---

7. Press **ON LINE** to engage the new setting and to exit the menu.  
*The printer returns to standby mode.*

# SUMMARY OF MENU DEFAULTS

## Menu Defaults

**Note:** Menus/Items with a dagger (†) only appear when the appropriate option (e.g., Duplex Unit, Second Paper Tray, etc.) is installed.

Menu	Item	Default Setting
INFORMATION MENU	PRINT MENU MAP	[EXECUTE]
	DEMO1	[EXECUTE]
PRINT MENU	COPIES	1
	DUPLEX†	OFF
	PAPER FEED	TRAY1
	AUTO TRAY SWITCH	ON
	TRAY SEQUENCE	DOWN
	MP TRAY USAGE	DO NOT USE
	MEDIA CHECK	ENABLE
	MONO-PRINT SPEED	AUTO
MEDIA MENU	TRAY1 PAPERSIZE	LETTER
	TRAY1 MEDIATYPE	PLAIN
	TRAY1 MEDIAWEIGHT	MEDIUM
	TRAY2 PAPERSIZE†	LETTER
	TRAY2 MEDIATYPE†	PLAIN
	TRAY2 MEDIAWEIGHT†	MEDIUM
	MPT PAPERSIZE	LETTER
	MPT MEDIATYPE	PLAIN
	MPT MEDIAWEIGHT	MEDIUM
	UNIT OF MEASURE	INCH
	X DIMENSION	8.5 INCH
	Y DIMENSION	11.0 INCH



## Menu Defaults (cont.)

**Note:** Menus/Items with a dagger (†) only appear when the appropriate option (e.g., Duplex Unit, Second Paper Tray, etc.) is installed.

Menu	Item	Default Setting
COLOR MENU	DENSITY CONTROL	AUTO
	ADJUST DENSITY	[EXECUTE]
	AJST REGISTRATION	[EXECUTE]
	C REG FINE AJST	0
	M REG FINE AJST	0
	Y REG FINE AJST	0
SYS CONFIG MENU	POW SAVE TIME	60 MIN
	CLRABLE WARNING	ON
	MANUAL TIMEOUT	60 SEC
	WAIT TIMEOUT	90 SEC
	LOW TONER	CONTINUE
	JAM RECOVERY	ON
	ERROR REPORT	OFF
	LANGUAGE	ENGLISH
USB MENU	SOFT RESET	DISABLE
	SPEED	480Mbps
NETWORK MENU	TCP/IP	ENABLE
	NETBEUI	DISABLE
	IP ADDRESS SET	AUTO
	IP ADDRESS	192.168.100.100
	SUBNET MASK	255.255.255.000
	GATEWAY ADDRESS	192.168.100.254
	INITIALIZE NIC?	[EXECUTE]
	WEB/IPP	ENABLE
	TELNET	ENABLE

## Menu Defaults (cont.)

**Note:** Menus/Items with a dagger (†) only appear when the appropriate option (e.g., Duplex Unit, Second Paper Tray, etc.) is installed.

Menu	Item	Default Setting
NETWORK MENU (CONT.)	FTP	ENABLE
	SNMP	ENABLE
	LAN	NORMAL
	HUB LINK SETTING	AUTO NEGOTIATE
MEMORY MENU†	RECEIVE BUF SIZE	AUTO
	FLASH INITIALIZE	[EXECUTE]
SYS ADJUST MENU†	X ADJUST	0.00 MILLIMETER
	Y ADJUST	0.00 MILLIMETER
	DUPLEX X ADJUST	0.00 MILLIMETER
	DUPLEX Y ADJUST	0.00 MILLIMETER
	DRUM CLEANING	OFF
MAINTENANCE MENU	MENU RESET	[EXECUTE]
	SAVE MENU	[EXECUTE]
	POWER SAVE	ENABLE
	PAPER BLACK SET	0
	PAPER COLOR SET	0
	TRNSPR BLACK SET	0
	TRANSPR COLOR SET	0
USAGE MENU	TRAY1 PAGE COUNT	nnnn
	TRAY2 PAGE COUNT†	nnnn
	MPT PAGE COUNT	nnnn

## Menu Defaults (cont.)

**Note:** Menus/Items with a dagger (†) only appear when the appropriate option (e.g., Duplex Unit, Second Paper Tray, etc.) is installed.

Menu	Item	Default Setting
USAGE MENU (CONT.)	COLOR PAGE COUNT	nnnn
	MONO PAGE COUNT	nnnn
	K DRUM LIFE	REMAINING nn%
	C DRUM LIFE	REMAINING nn%
	M DRUM LIFE	REMAINING nn%
	Y DRUM LIFE	REMAINING nn%
	BELT LIFE	REMAINING nn%
	FUSER LIFE	REMAINING nn%
	K TONER	REMAINING nn%
	C TONER	REMAINING nn%
	M TONER	REMAINING nn%
	Y TONER	REMAINING nn%

# PRINTER MENUS

## Information Menu

Item	Action	Explanation
PRINT MENU MAP	EXECUTE	Prints the MenuMap (menu listing) with current settings shown. Information about your printer is also shown at the top of each MenuMap page.
DEMO1	EXECUTE	Prints the built-in Demo page.

## Print Menu

**Note:** Factory default settings are shown in **bold**.

Item	Settings	Explanation
COPIES	<b>1</b> to 999	Enter the number of copies of a document to be printed.
PAPER FEED	<b>TRAY1</b> TRAY2 MP TRAY	Selects the default tray for paper feed.
AUTO TRAY SWITCH	<b>ON</b> OFF	If two trays contain identical print media, the printer can switch to an alternate tray when the current tray runs out in the middle of a print job.
TRAY SEQUENCE	<b>DOWN</b> UP PAPER FEED TRAY	Sets the sequence in which the printer will seek an alternate tray with the same media size should the currently selected tray run out of media while printing a job.

## Print Menu (cont.)

**Note:** Factory default settings are shown in **bold**.

Item	Settings	Explanation
MP TRAY USAGE	<b>DO NOT USE</b> WHEN MISMATCHXXX	If a document to be printed demands a paper size not installed in the selected tray, the printer can automatically feed from the Multi-Purpose Tray instead. If this function is not enabled, the printer will stop and request that the correct size be loaded.
MEDIA CHECK	<b>ENABLE</b> DISABLE	Set to DISABLE if you do not wish the printer to check to see if the size paper loaded in the selected tray matches that required for the document being printed.
MONO-PRINT SPEED	<b>AUTO</b> COLOR SPEED NORMAL SPEED	Sets the print engine speed. If you are printing only color documents, switch to COLOR SPEED.  If you are printing only monochrome documents, switch to NORMAL SPEED.

## Media Menu

### Notes:

- Factory default settings are shown in **bold**.
- Menus/Items with a dagger (†) only appear when the appropriate option (e.g., Duplex Unit, Second Paper Tray, etc.) is installed.

Item	Settings	Explanation
TRAY1 PAPERSIZE	A4, A5, A6, B5 LEGAL14 LEGAL13.5 LEGAL13 <b>LETTER</b> EXECUTIVE CUSTOM	Defines the size of paper loaded in Tray 1.
TRAY1 MEDIATYPE	<b>PLAIN</b> LETTERHEAD BOND RECYCLED ROUGH	Defines the type of media loaded in Tray 1. This will help the printer to adjust its internal operating parameters, such as engine speed and fusing temperature.
TRAY1 MEDIAWEIGHT	LIGHT <b>MEDIUM</b> HEAVY	Adjusts the printer for the weight of paper stock loaded in the tray. (See “Media Weight Designations” on page 11.)
TRAY2 PAPERSIZE†	A4, A5, B5, LEGAL14 LEGAL13.5 LEGAL13 <b>LETTER</b> EXECUTIVE CUSTOM	Defines the size of paper loaded in optional Tray 2.
TRAY2 MEDIATYPE†	<b>PLAIN</b> LETTERHEAD BOND RECYCLED ROUGH	Defines the type of media loaded in optional Tray 2.
TRAY2 MEDIAWEIGHT†	LIGHT <b>MEDIUM</b> HEAVY	Adjusts the printer for the weight of paper stock loaded in optional Tray 2.

## Media Menu (cont.)

### Notes:

- Factory default settings are shown in **bold**.
- Menus/Items with a dagger (†) only appear when the appropriate option (e.g., Duplex Unit, Second Paper Tray, etc.) is installed.

Item	Settings	Explanation
MPT PAPERSIZE	<b>LETTER</b> EXECUTIVE LEGAL14 LEGAL13.5 LEGAL13 A4, A5, A6, B5 CUSTOM COM-9 ENVELOPE COM-10 ENVELOPE MONARCH ENV DL ENVELOPE C5 ENVELOPE	Defines the size of paper to be fed from the Multi-Purpose Tray.
MPT PAPERTYPE	<b>PLAIN</b> LETTERHEAD TRANSPARENCY LABELS BOND RECYCLED CARD STOCK ROUGH GLOSSY	Defines the type of media to be fed from the Multi-Purpose Tray so that the printer can adjust its internal parameters for the media.
MPT MEDIAWEIGHT	<b>MEDIUM</b> HEAVY ULTRA HEAVY	Defines the media weight to be fed from the Multi-Purpose Tray.
UNIT OF MEASURE	MILLIMETER <b>INCH</b>	Defines the unit of measure for the next two items.
X-DIMENSION	3 to 8.5 INCH Default = <b>8.5 INCH</b>	Defines the width of paper defined by the "CUSTOM" settings.

## Media Menu (cont.)

### Notes:

- Factory default settings are shown in **bold**.
- Menus/Items with a dagger (†) only appear when the appropriate option (e.g., Duplex Unit, Second Paper Tray, etc.) is installed.

Item	Settings	Explanation
Y-DIMENSION	5 to 35.5 INCH Default = <b>11 INCH</b>	Defines the length of paper defined by the "Custom" settings. Note that media of up to 47" (1.2 m) in length can be fed one sheet at a time from the Multi-Purpose Tray-for banner printing.



## NOTE

The printer automatically adjusts color balance and density at appropriate intervals, optimizing the printed output for bright white paper viewed in natural daylight conditions. The items on this menu provide a means of changing the default settings for special or particularly difficult print jobs. Settings revert to their default values when the next print job is complete.

## Color Menu

**Note:** Factory default settings are shown in **bold**.

Item	Settings	Explanation
DENSITY CONTROL	<b>AUTO</b> MANUAL	AUTO = image density is automatically adjusted: <ul style="list-style-type: none"> <li>• at power on</li> <li>• when a new image drum or toner cartridge is installed</li> <li>• at intervals of 100, 300 and 500 drum counts</li> </ul> Auto adjustment takes up to 55 seconds. Switch to manual only if you wish to initiate Density Control manually using the printer menu.
ADJUST DENSITY	[EXECUTE]	Selecting this will perform the auto density set up.
AJST REGISTRATION	[EXECUTE]	Performs automatic color registration adjustment. Normally this is done at power on and when the top cover is opened and then closed. This process accurately aligns the cyan, magenta and yellow images to the black image.
C REG FINE ADJUST M REG FINE ADJUST Y REG FINE ADJUST	-3 to + 3 in increments of 1 Default = <b>0</b>	Performs fine adjustment of image timing in relation to the black image component. A positive setting will darken the color; a negative setting will lighten the color.

## System Configuration Menu

**Note:** Factory default settings are shown in **bold**.

Items	Settings	Explanation
POW SAVE TIME	5 15 30 <b>60</b> 240	Adjusts the time before the printer automatically switches into power saving mode. In this mode power consumption is reduced, but when a job is sent the printer will require a warm-up time of up to 1 minute before printing can begin.
CLEARABLE WARNING	<b>ON</b> JOB	When ON, non-critical warnings, such as requests for a different paper size, can be cleared by pressing the <b>ON LINE</b> button. When set to JOB, they are only cleared when the print job resumes.
MANUAL TIMEOUT	OFF 30 <b>60</b>	Specifies how many seconds the printer will wait for paper to be fed before cancelling the job.
WAIT TIMEOUT	5 to 300 SEC Default = <b>90</b> seconds	Specifies how many seconds the printer will wait when received data pauses before forcing a page eject.
LOW TONER	<b>CONTINUE</b> STOP	Specifies whether the printer should continue printing after a low toner condition is detected. If you change this to STOP, when low toner is detected, the printer goes off line.
JAM RECOVERY	<b>ON</b> OFF	Specifies whether the printer should perform jam recovery after a paper jam has occurred. If ON, the printer will attempt to print again any pages lost due to a paper jam once the jam has been cleared.
ERROR REPORT	ON <b>OFF</b>	Change this to ON if you wish the printer to print the error details when an error occurs.

## System Configuration Menu (cont.)

**Note:** Factory default settings are shown in **bold**.

Items	Settings	Explanation
LANGUAGE	<b>English</b> German French Italian Spanish Swedish Norwegian Danish Dutch Turkish Portuguese Polish	Sets the language used for the display window and printed reports.

## USB Menu

**Note:** Factory default settings are shown in **bold**.

Item	Settings	Explanation
SOFT RESET	ENABLE <b>DISABLE</b>	Enables or disables the SOFT RESET command.
SPEED	<b>480Mbps</b> 12Mbps	Sets the maximum transfer speed for the USB interface.

## Network Menu

**Note:** Factory default settings are shown in **bold**.

Item	Settings	Explanation
TCP/IP	<b>ENABLE</b> DISABLE	Enables or disables this network protocol.
NETBEUI	ENABLE <b>DISABLE</b>	Enables or disables this network protocol.

## Network Menu (cont.)

**Note:** Factory default settings are shown in **bold**.

Item	Settings	Explanation
IP ADDRESS SET	<b>AUTO</b> MANUAL	Change this to Manual to specify the IP address through the front panel.(see next entry) Required for non-DHCP networks.
IP ADDRESS	xxx.xxx.xxx.xxx Default = 198.168.100.100	Current assigned IP address. To change: <ul style="list-style-type: none"> <li>• Press <b>ENTER</b>.</li> <li>• Use <b>+/-</b> keys to increment first octet.</li> <li>• Press <b>ENTER</b> to move on to the next octet.</li> <li>• Use <b>+/-</b> keys to increment second octet.</li> <li>• Press <b>ENTER</b> to move on to the next octet.</li> <li>• Use <b>+/-</b> keys to increment third octet.</li> <li>• Press <b>ENTER</b> to move on to the last octet.</li> <li>• Use <b>+/-</b> keys to increment 1st octet.</li> <li>• Press <b>ENTER</b> to register the new address.</li> </ul>
SUBNET MASK	xxx.xxx.xxx.xxx Default = 255.255.255.000	Current assigned subnet mask. To change, proceed as above.
GATEWAY ADDRESS	xxx.xxx.xxx.xxx Default = 192.168.100.254	Current assigned gateway address. To change, proceed as above.
INITIALIZE NIC?	[EXECUTE]	Initializes the network card.
WEB/IPP	<b>ENABLE</b> DISABLE	Enables or disables Web config. facility and Internet Printing Protocol. This item will not appear in the menu if TCP/IP is set to DISABLE.
TELNET	<b>ENABLE</b> DISABLE	Enables or disables Telnet config. facility. This item will not appear in the menu if TCP/IP is set to DISABLE.

## Network Menu (cont.)

**Note:** Factory default settings are shown in **bold**.

Item	Settings	Explanation
FTP	<b>ENABLE</b> DISABLE	Enables or disables communication via FTP. This item will not appear in the menu if TCP/IP is set to DISABLE.
SNMP	<b>ENABLE</b> DISABLE	Enables or disables SNMP protocol.
LAN	<b>NORMAL</b> SMALL	Normal = Global network Small = Local network
HUB LINK SETTING	<b>AUTO NEGOTIATE</b> 100BASE-TX FUL 100BASE-TX HALF 10BASE-T FULL 10BASE-T HALF	Sets full or half duplex for communication via a network hub.

## Memory Menu

**Note:** Factory default settings are shown in **bold**.

Item	Settings	Explanation
RECEIVE BUF SIZE	<b>AUTO</b> 0.5MB 1MB 2MB 4MB 8MB 16MB	Sets the size of the receive buffer.

## Memory Menu (cont.)

**Note:** Factory default settings are shown in **bold**.

Item	Settings	Explanation
FLASH INITIALIZE	[EXECUTE]	Initializes Resident Flash memory. When ENTER is pressed, the following message displays. ARE YOU SURE? YES=ENTER/NO=CANCEL Press ENTER. The following message displays: EXECUTE NOW? YES=ENTER/NO=CANCEL Press ENTER, then turn the printer off. The request to execute FLASH initialization is put into the memory and initialization is executed when the power is turned back on.

## System Adjust Menu

### Notes:

- Factory default settings are shown in **bold**.
- Menus/Items with a dagger (†) only appear when the Duplex Unit is installed.

Item	Settings	Explanation
X ADJUST	-2.00MILLIMETER TO +2.00MILLIMETER Default = <b>0.00</b>	Adjusts overall print position horizontally in 0.25 increments.
Y ADJUST	-2.00MILLIMETER TO +2.00MILLIMETER Default = <b>0.00</b>	Adjusts overall print position vertically in 0.25 increments.
DUPLEX X ADJUST†	-2.00MILLIMETER TO +2.00MILLIMETER Default = <b>0.00</b>	Adjusts overall print position of print face horizontally in 0.25 increments.
DUPLEX Y ADJUST†	-2.00MILLIMETER TO +2.00MILLIMETER Default = <b>0.00</b>	Adjusts overall print position of print face vertically in 0.25 increments.

## System Adjust Menu (cont.)

### Notes:

- Factory default settings are shown in **bold**.
- Menus/Items with a dagger (†) only appear when the Duplex Unit is installed.

Item	Settings	Explanation
DRUM CLEANING	<b>OFF</b> ON	If you are experiencing horizontal white lines on your printed pages, enter the menu and temporarily change this setting to ON, then send a one page print job. This will cause an extra blank sheet to print, cleaning the drum prior to printing. <b>Careful!</b> Leaving this set to ON will reduce the image drum life.

## Maintenance Menu

**Note:** Factory default settings are shown in **bold**.

Item	Settings	Explanation
MENU RESET	[EXECUTE]	Resets menus to the default settings.
SAVE MENU	[EXECUTE]	Saves current menu settings as default values. At confirmation prompt, press <b>ENTER</b> to confirm save, or <b>CANCEL</b> .
POWER SAVE	<b>ENABLE</b> DISABLE	Change this setting to Disable if you do not want the printer to enter the power save mode after the specified time.
PAPER BLACK SETTING	-2 to +2 in increments of 1 Default = <b>0</b>	Used for small adjustment when you experience faded print or light specks / streaking in monochrome printing on white paper. Select a higher value to reduce fading, or a lower value to reduce specks or streaking in high density print areas.
PAPER COLOR SETTING	-2 to +2 in increments of 1 Default = <b>0</b>	As above, but for color printing.
TRANSPR BLACK SETTING	-2 to +2 in increments of 1 Default = <b>0</b>	As above, but for mono printing on transparencies.
TRANSPR COLOR SETTING	-2 to +2 in increments of 1 Default = <b>0</b>	As above, but for color printing on transparencies.



## Usage Menu

This menu is for information only, and provides an indication of total usage of the printer and the expected life left in its consumable items. This is particularly useful if you do not have a full set of replacement consumables on hand and you need to know how soon you will need them.

Item	Explanation
TRAY1 PAGE COUNT	The total number of pages fed from Tray 1.
TRAY2 PAGE COUNT	The total number of pages fed from optional Tray 2. Appears only if the optional Second Paper Tray (see "Second Paper Tray" on page 114) is installed.
MPT PAGE COUNT	The total number of pages fed from the Multi-Purpose Tray.
COLOR PAGE COUNT	The total number of pages printed in color.
MONO PAGE COUNT	The total number of pages printed in monochrome.
K DRUM LIFE C DRUM LIFE M DRUM LIFE Y DRUM LIFE	Percentage of life remaining in these consumable items is indicated as nn%.
K TONER C TONER M TONER Y TONER	Current remaining toner is indicated as nn%.

# Replacing Consumables

- **Toner Cartridge** — Life expectancy approximately 5,000 pages, assuming about 5% coverage, which means that 5% of the addressable dots in an image are printed with this color of toner. See “Toner Cartridge Replacement” on page 87.

## NOTE

When installing a toner cartridge in a new image drum, the life expectancy of the cartridge will be reduced by approximately 1,500 pages (at 5% coverage) as the toner charges the new drum.

- **Image Drum** — Life expectancy approximately 15,000 pages, assuming an average of 3 pages per print job. If the average print job is longer than this, the image drums could last longer, but if the average print job is shorter, then image drums will be used more quickly. See “Image Drum Replacement” on page 94.
- **Transfer Belt** — Life expectancy about 50,000 letter-size pages. See “Belt Unit Replacement” on page 103.
- **Fuser** — Life expectancy about 45,000 letter-size pages. See “Fuser Replacement” on page 108.

# TONER CARTRIDGE REPLACEMENT

REPLACE TONER

nnn: ZZZZ TONER EMPTY

- \* nnn: ZZZZ =410: YELLOW  
411: MAGENTA  
412: CYAN  
413: BLACK

Toner Color	Oki Order #
Black	42127404
Cyan	42127403
Magenta	42127402
Yellow	42127401


1. Press the cover release and open the printer's top cover fully.




### **WARNING!**

***If the printer has been powered on, the fuser is hot. This area is clearly labelled. Do not touch.***


2. Note the positions of the four cartridges: Cyan (1), Magenta (2), Yellow (3), Black (4):



3. Pull the colored toner release lever on the cartridge to be replaced (here we are showing replacement of the black toner cartridge) towards the front of the printer.



4. Lift the right-hand end of the cartridge and then pull the cartridge to the right to release the left-hand end as shown. Remove the toner cartridge and discard it in accordance with your local regulations.



5. Unpack the new toner cartridge and gently shake it *from side to side* to loosen and distribute the toner evenly inside the cartridge.





6. Remove the adhesive tape from the underside of the cartridge.




## CAUTION!

**Do not touch the toner release lever until the toner cartridge is installed in the image drum. If you do, it will open the toner release slot and spill toner.**

7. Holding the cartridge by its top center with the colored release lever to the right, insert the left end of the cartridge into the top of the image drum, pushing it firmly against the spring on the drum unit.



8. Lower the right end of the cartridge into the image drum unit, pressing it firmly down in place, then push the colored lock lever back to open the toner slot and lock it in place.



### Important!

The lever should move easily. If it does not, **STOP!** and push down on the toner cartridge to be sure that it is properly seated in the image drum, then press back on the lever again.

To avoid toner spillage, do NOT open the toner release lever until the toner cartridge is firmly seated in the image drum.



9. Close and latch the top cover.



# IMAGE DRUM REPLACEMENT

---

REPLACE IMAGE DRUM

nnn: ZZZZ DRUM LIFE

---

- \* nnn: ZZZZ = 350: YELLOW  
351: MAGENTA  
352: CYAN  
353: BLACK

Drum Color	Oki Order #
Black	42126604
Cyan	42126603
Magenta	42126602
Yellow	42126601

1. Place two sheets of paper on your working surface to protect it. You will put the image drum and toner cartridge on the paper while replacing them.


2. Press the cover release and open the top cover fully.



### **WARNING!**

***If the printer has been powered on, the fuser is hot. This area is clearly labelled. Do not touch it.***

3. Note the positions of the four image drums: Cyan (1), Magenta (2), Yellow (3), Black (4):



4. Lift the image drum, complete with its toner cartridge, out of the printer and put it down on one of the sheets of paper.



5. With the colored toner release lever (1) to the right, pull the lever towards you. This will release the bond between the toner cartridge and the image drum.



6. Lift the right-hand end of the toner cartridge, move the cartridge to the right, and remove the toner cartridge from the image drum. Place the toner cartridge on a sheet of paper to avoid marking your furniture.



7. Discard the used image drum in accordance with your local regulations.


### **CAUTION!**

**The green image drum surface at the base of the cartridge is very delicate and light sensitive. Do not touch it and do not expose it to normal room light for more than 5 minutes. If the drum unit needs to be out of the printer for longer than this, please wrap the cartridge inside a black plastic bag to keep it away from light. Never expose the drum to direct sunlight or very bright room lighting.**

8. Unpack the new image drum.

**CAUTION!**



**Image drum handling:** The image drum contains toner. To avoid spilling toner, be careful to *keep it upright*.



**9.** Grasp the white tape tab and peel the tape off the drum.



**10.** Remove the paper sheet, then the clear plastic film.



**11. Remove the silica gel pack.**



**12. Place the image drum in the printer.**






**13.** Remove the orange drum seal.



**14.** Install the toner cartridge in the image drum.



**15.** Push back the toner cartridge lock lever.



**16.** Close and latch the top cover.



# BELT UNIT REPLACEMENT

## OKI 42158701

---

REPLACE BELT  
355: BELT LIFE

---

The belt unit is located under the four image drums. This unit requires replacement approximately every 50,000 pages.


1. Press the cover release and open the top cover fully.



### **WARNING!**

*If the printer has been powered on, the fuser is hot. This area is clearly labelled. Do not touch it.*

2. Note the positions of the four image drums: Cyan (1), Magenta (2), Yellow (3), Black (4). ***It is essential that they go back in the correct order!***




3. Lift each of the image drum units out of the printer and place them on a *flat* surface in a safe place away from direct sources of heat and light.

### CAUTION!


The green surface at the base of each image drum is very delicate and light sensitive.

- Do not touch the green surface.
- Never expose the drum to direct sunlight or to very bright room lighting.
- Do not expose it to normal room light for more than 5 minutes.
- If the image drum must be out of the printer for longer than 5 minutes, place the image drum inside a black plastic bag or carefully place it in a drawer or cabinet to keep it away from light.

4. Locate the two blue locks (1) and the handle (2).




5. Turn the two locks about 45° *counterclockwise* to release the belt.




6. Pull up the handle and lift the belt unit out of the printer.




7. Unpack the new belt unit and hold it with the blue handle toward the front of the printer.
8. Place the drive gear at the back of the belt unit in the gear at the left rear corner of the printer, and lower the belt unit into the printer.



- 9.** Turn the two belt locks about 45° clockwise to secure the belt unit in place.



- 10.** Place the four image drums/toner cartridges back in the printer (1 = Cyan, 2 = Magenta, 3 = Yellow, 4 = Black):



11. Close and latch the top cover.



## FUSER REPLACEMENT

**OKI 42158601 (120V)**

**OKI 42158602 (230V)**

---

REPLACE FUSER  
354: FUSER LIFE

---

### **WARNING!**

*If the printer has recently been powered on, some fuser components will be very hot. Handle the fuser with extreme care, holding it only by its handle, which will only be mildly warm to the touch.*


*A warning label clearly indicates the area. If in doubt, switch the printer off and wait at least 10 minutes for the fuser to cool before opening the printer cover.*



1. Press the cover release and open the printer's top cover fully.




2. Pull the two blue fuser lock levers (1) towards the front of the printer.




3. Holding the fuser **by its handle**, lift the fuser out of the printer. *If the fuser is still warm, place it on a flat surface which will not be damaged by heat.* After letting the fuser cool down, discard it.




4. Remove the new fuser from its packaging, then remove any packing tape.
5. Push the orange transport lock to the left to release it (you'll hear it snap), then remove it:



6. Holding the new fuser by the handle, with the fuser pressure release lever (1) on the right, lower the fuser into the printer.



7. Push the two blue retaining levers (1) toward the rear of the printer to lock the fuser in place.



**8. Close and latch the top cover.**



# Options


The following options are available for your printer:

- Additional RAM memory (see below)
- Second Paper Tray (see page 114)
- Duplex Unit, for two sided printing (see page 115)

Instructions for installing these options are found in the packaging with the option.

## RAM MEMORY

**(Oki 70042801, 70042901)**




The basic printer comes equipped with 32 MB of main memory. This can be upgraded with an additional memory board containing

- 64 MB (Oki 70042801)
- 256 MB (Oki 70042901)

giving a maximum total memory capacity of 288 MB.

## **SECOND PAPER TRAY**

**(Oki 42158501)**




The second paper tray takes:

- Up to 530 sheets of 20-lb. paper.
- All the same size media as Tray 1 except A6.
- Paper weight range 16 to 57 lbs. (60 to 203 g/m<sup>2</sup>).

## **DUPLEX UNIT**

**(Oki 42158401)**



The duplex unit adds the function of two sided printing and enables booklet printing. The duplex unit slides straight into the rear of the printer and requires no tools to install.

The duplex unit handles:

- Paper sizes letter, legal-14, legal-13.5, legal-13, A4, A5, B5.
- Paper weights from 20 to 28 lbs.  
(42 to 58 lb. Index, 75 to 105 g/m<sup>2</sup> metric).

# Clearing Paper Jams

Jams can occur due to paper misfeeding from a paper tray or at any point along the paper path.

When a jam occurs, the printer immediately stops, and the LCD display indicates the area where the first sheet is jammed. All jammed sheets must be removed in order to restore the printer to normal operation.

Once you clear a jam and close the cover, you may see a new jam message indicating an additional jammed sheet which must be cleared. This is especially likely if you are printing a multi-page document or multiple copies of a single document.

Unless you have entered the menu and changed the Jam Recovery setting in the System Configuration Menu to OFF, once all jams have been cleared, the printer will automatically attempt to reprint any pages lost due to paper jams.

- Jam 370: see page 128
- Jam 371: see page 130
- Jam 372: see page 126
- Jam 373: see page 128
- Jam 380: see page 126
- Jam 381: see page 120
- Jam 382: see page 117
- Jam 383: see page 128
- Jam 390: see page 135
- Jam 391: see page 133
- Jam 392: see page 133




## Jam 382

---

### OPEN TOP COVER 382: PAPER JAM


---

1. Open the top cover.




2. Gently pull the sheet out.


- If the sheet does *not* come out easily, go to the next step.
- If the sheet does come out, close the cover.



3. Lower the rear exit tray.




4. Pull out the jammed sheet.




### Important!

**WARNING! The fuser may be HOT!**

If the sheet is difficult to remove, it is partially jammed in the fuser. To get it out, reach around the top cover and press down on the fuser pressure release lever (1) before pulling the sheet out. Then let go of the fuser pressure release lever.



**5. Close the rear exit.**



**6. Close the top cover.**



## Jam 381

---


### OPEN TOP COVER 381: PAPER JAM

---

1. Press the cover release and open the printer's top cover fully.



2. Note the positions of the four image drums: Cyan (1), Magenta (2), Yellow (3), Black (4). *It is essential that they go back in the correct order!*



### **WARNING!**

*If the printer has been powered on, the fuser is hot. This area is clearly labelled. Do not touch it.*

3. Lift each of the image drum/toner cartridge units out of the printer and place them on a *flat* surface in a safe place *away from direct sources of heat and light*.



### **CAUTION!**

The green surface at the base of each image drum is very delicate and light sensitive.

- Do not touch the green surface.
- Never expose the drum to direct sunlight or to very bright room lighting.
- Do not expose it to normal room light for more than 5 minutes.
- If the image drum must be out of the printer for longer than 5 minutes, place the image drum inside a black plastic bag or carefully place it in a drawer or cabinet to keep it away from light.

4. Remove any sheets of paper on the belt unit.




### **CAUTION!**

**Do not use any sharp or abrasive objects to separate sheets from the belt. This may damage the belt surface.**

## NOTE

**Warning! If the printer has been printing, the fuser will be *HOT!***


To remove a sheet trapped in the fuser, grasp the edge of the sheet, push the fuser pressure release lever (1) towards the front and down, and lift out the sheet. Then let go of the fuser pressure release lever.



If the sheet is well advanced into the fuser (only a short length is still visible), do not attempt to pull it back. See step 4 under “Jam 382” .



5. Place the four image drums/toner cartridges back in the printer, being careful to place them in the proper sequence (**1** = Cyan, **2** = Magenta, **3** = Yellow, **4** = Black):



6. Close the top cover.



## Jam 372 and 380

---

### OPEN FRONT COVER

nnn: PAPER JAM

---

nnn = 372 or 380.


1. Lift the front cover release and pull open the front cover.



2. Remove any jammed sheets.



**3. Close the front cover.**



## **Jam 370, 373 and 383**

---


OPEN DUPLEX COVER

nnn: PAPER JAM




---

nnn = 370, 373, 383


1. Press the duplex cover release and open the duplexer cover.



**2. Remove any jammed sheets.**



3. Close the duplex unit cover.



## **Jam 371**

---

### OPEN DUPLEX COVER 371: PAPER JAM

---

1. Turn off the printer.
2. Pull out the duplexer.




**3. Pull the duplexer lid to unlock it.**




**4. Open the lid and remove the jammed sheet.**



5. Close the lid and push it back to lock it in place.



6. Push the duplexer back into the printer.



7. Turn on the printer



## **Jam 391 and 392**

---

OPEN FRONT COVER  
nnn: PAPER JAM

---

---


OPEN FRONT COVER  
392: PAPER JAM

---

1. Pull out the appropriate tray (391 = Tray 1, 392 = Optional Tray 2) and remove any sheet jammed as it exited the tray.



**391**




**392**


**2. Open the front cover.**



**3. Remove any jammed sheets.**



**4. Close the front cover.**



## **Jam 390**


---

CHECK MP TRAY  
390: PAPER JAM

---


### **If the Sheet Has Just Begun to Enter the Printer**

1. Gently pull the sheet out of the printer.




### **If the Sheet Can't Easily Be Pulled Out from the Front**


1. Lift the front cover release and pull open the front cover.



**2. Remove any jammed sheets.**






**3. Close the front cover.**



# Troubleshooting

## LCD MESSAGES

Message	Meaning	What to Do
* TONER SENSOR ERROR	Flashes across the second line of the display: the indicated color toner (*) is missing from the printer.	Open the top cover and make sure the indicated toner is there and properly seated in the printer: C = Cyan, Y = Yellow, M = Magenta, K = Black.
ADD MORE MEMORY 420: MEMORY OVERFLOW	The document size is too large for the printer's memory.	Reduce the size of the document. If this happens frequently, install additional memory (see "RAM Memory" on page 113).
CANCELLING JOB (JAM)	The setting for Jam Recovery in the menu has been changed to off and a paper jam has occurred. Any unprinted data is being deleted.	Clear the jam and resend the missing pages of the print job.
CHECK BELT 330: BELT MISSING	The belt unit is not properly installed.	<p>Open the top cover and lift out the black (K) and Yellow (Y) image drums, placing them on a <i>flat</i> surface. Check to be sure that the belt unit latches are fully in the latched position:</p>  <p>then reinstall the image drums.</p>

Message	Meaning	What to Do
CHECK FUSER 320: FUSER MISSING	The fuser unit is not properly installed.	Open the top cover and check to be sure that the fuser unit is properly seated in the printer and that the lock levers are pushed all the way toward the back of the printer: 
CHECK MP TRAY 390: PAPER :JAM	Paper has jammed while exiting the MP Tray.	Clear the jam: see "Jam 390" on page 135.
CLOSE COVER 316: DUPLEX COVER OPEN	The duplex cover is open or not properly latched.	Close the duplex cover: 
CLOSE COVER nnn: COVER OPEN	Either the top cover or the front cover is open.	Be sure both the top cover and the front cover are firmly closed.
INSTALL PAPER CASSETTE 430: TRAY 1 MISSING	Tray 1 is not installed in the printer.	Install the missing tray.
INSTALL PAPER CASSETTE 440: TRAY 1 OPEN	Tray 1 is not properly installed in the printer.	Make sure the tray is pushed fully into the printer.

Message	Meaning	What to Do
LOAD mmm AND PRESS ONLINE SWITCH 490: MP TRAY EMPTY	Print job from MP Tray has been received and the MP Tray is empty.	Load the requested media (mmm) in the MP Tray and press <b>ON-LINE</b> .
LOAD mmm nnn: tttt EMPTY	A print job has been received and the indicated paper tray is empty.	Load mmm media in the indicated (tttt) tray.
LOAD mmm/ppp AND PRESS ONLINE SWITCH nnn: tttt MEDIA MISMATCH	The media type in the indicated tray (tttt) does not match that specified in the print job being processed.	Load the appropriate media in the tray and press <b>ON-LINE</b> .
LOAD mmm/ppp AND PRESS ONLINE SWITCH nnn: tttt SIZE MISMATCH	The media size (mmm) and/or type (ppp) loaded in the indicated tray (tttt) does not match that specified in the print job being processed.	Load the appropriate media in the tray and press <b>ON-LINE</b> .
OPEN DUPLEX COVER nnn: PAPER JAM	Paper has jammed entering or exiting the duplexer.	Clear the jam: see page 128 and page 130.
OPEN FRONT COVER nnn: PAPER JAM	Paper jam.	Clear the jam: see page 126 and page 133
OPEN TOP COVER nnn: PAPER JAM	Paper jam.	Clear the jam: see page 117 and page 120.
ORDER xxx	Appears on the second line of the display to indicate that consumable xxx (e.g., belt, fuser, toner, image drum) is nearing end of life.	Make sure you have a replacement unit on hand.

Message	Meaning	What to Do
POWER ON/OFF 300: NETWORK ERROR	An error has occurred involving the network.	Shut the printer off, then turn it back on. If the message still appears, check with your network administrator.
PRESS ONLINE SW INVALID DATA	The printer has received invalid data.	Press <b>ON-LINE</b> . Reprocess and resend the print job.
REPLACE TONER nnn: * TONER EMPTY	The indicated toner needs replacement.	Replace the indicated toner: 410: Y = Yellow 411 M = Magenta 412: C = Cyan 413: K = Black
REPLACE YYYY nnn: YYYY LIFE	The indicated component is nearing end of life and should be replaced.	Replace the indicated component: YYYY = Fuser, Belt, C Drum, Y Drum, M Drum, K Drum.
tttt EMPTY	Appears on the second line of the display to indicate that ttt tray has run out of media.	Load media in tray tttt.
xxx LIFE	Appears on the second line of the display to indicate that consumable xxx (e.g., belt, fuser, image drum) will need to be replaced soon.	Replace the indicated item.



Message	Meaning	What to Do
YYYY nnn: FATAL ERROR	An error has occurred which requires service. YYYY = the general cause. nnn = error number.	Try turning off the printer then turning it back on. If this does not remedy the problem, write down the message including the error number “nnn,” then call your authorized Oki Data Service Dealer for service. <b>Note:</b> If you see a series of octets containing letters and numbers scrolling across the display, be sure to write these down also and report them to the Service Dealer.

## PROBLEM SOLVING

### Paper feed problems.

If paper jams are frequent:

- More than one sheet feeds at a time.
- Paper curls.
- Paper feeds at an angle.

Possible cause	Remedy
The printer is not horizontal.	Place the printer on a stable, level surface.
The paper is too thin.	Use the correct type of paper (see “Media Weight Designations” on page 11).
The paper is moist or affected by static.	Store paper within specified temperature and humidity levels (see “Specifications” on page 152).
The paper is creased or wrinkled.	Remove the creased/wrinkled paper from the feed tray.
The paper is not aligned correctly.	Adjust tray or manual feed guides.
Paper doesn't feed.	Correct paper feed selection in the Properties <b>Setup</b> tab in the printer driver.

### Paper jam has been cleared, but printer does not print.

Possible cause	Remedy
The top cover has not remained open until all paper jams have been cleared.	Removing a paper jam is not sufficient: Raise and <i>gently</i> lower the top cover, especially if the paper jam has been removed from behind the front cover.


# PROBLEMS PRINTING FROM WINDOWS

## Cannot configure for USB connection.

### NOTE

- Windows 95 and Windows NT 4.0 do not support USB.
- Windows 98 upgraded from Windows 95 may not support USB.
- Windows 98 original installation and Windows Me, 2000, and XP all support USB.

Possible cause	Remedy
Computer does not support USB interface.	Check if there is a USB controller in the Windows device manager.
USB cable does not meet specifications.	Use USB cable to specification Ver.1.1.
Interface is disabled.	Check that USB interface is set to Enable in the menu ( <b>USB MENU</b> → <b>USB</b> → <b>ENABLE</b> ).
Configuration procedure was not correctly followed or cancelled.	Configure again from the beginning.
USB cable is disconnected or faulty.	Reconnect or try another cable.
A USB hub is being used.	The printer cannot be used with a USB hub. Connect the printer and computer directly.

Possible cause	Remedy
<p>The USB cable is installed in the Ethernet port.</p>	<p>Make sure the USB cable is plugged into the white USB port (1) on the printer:</p>  <p>The image shows the rear panel of a printer. It features a 'LAN' port (Ethernet) and a 'USB' port. A red 'X' is placed over the LAN port, indicating it is incorrect to plug a USB cable there. A red line points from a red box containing the number '1' to the USB port, indicating it is the correct port for USB connection.</p>

## Cannot print.

- **PRNUSBX WRITE ERROR** is displayed.

Possible cause	Remedy
Interface is disabled.	In the printer menu settings, enable the USB interface ( <b>USB MENU</b> → <b>USB</b> → <b>ENABLE</b> ).
Printer is switched OFF.	Turn on the printer.
Printer interface cable is disconnected.	Reconnect the printer interface cable.
A converter, buffer, extension cable or USB hub is being used.	Test by connecting the printer and computer directly.
Printer driver output port is incorrect.	Set correct output port to which the printer interface cable is connected.
Printer is not selected in the printer driver.	Select the printer or set to default printer.
Incorrect printer driver is being used.	Delete this printer driver and install correct printer driver from the Drivers CD supplied with your printer.

## Application error or general protection fault is displayed.

Possible cause	Remedy
Application is not suitable for Windows version.	Upgrade the application.
Memory is insufficient for number of applications running.	Close all other applications.
Print file is corrupted.	Correct or recreate the file.
Memory is insufficient for application.	Increase computer's memory.
Printer driver is incorrectly configured.	Correctly configure printer driver.

## Printing is slow.

Possible cause	Remedy
Print processing is carried out by the computer.	Use a computer with a faster processor.
Print resolution is set high.	Set lower print resolution in the printer driver <b>Job Options</b> tab.
Data is too complex.	Simplify data.

## Printer requests paper size change to continue printing.

Possible cause	Remedy
Paper loaded in tray is different size from that formatted in software application.	Either change paper in tray to match size formatted in application and press <b>ON-LINE</b> to continue, or continue printing on existing paper by pressing <b>ON-LINE</b> .

## PROBLEMS WITH POOR QUALITY PRINTING

### Longitudinal white stripes

Remedy
Clean LED head with lens cleaner or soft tissue.
Change toner cartridge.
Change image drum.

### Longitudinal fading

Possible cause	Remedy
LED head is dirty.	Clean LED head with lens cleaner or soft tissue.
Toner is low.	Change toner cartridge.
Paper is unsuitable for printer.	Use recommended paper.

## Faint printing

Possible cause	Remedy
The toner cartridge is incorrectly installed.	Reinstall the toner cartridge (see page 87).
Toner is low.	Change toner cartridge (see page 87).
The paper is moist.	Store paper within specified temperature and humidity levels (see page 152).
Paper is unsuitable for printer.	Use recommended paper (see page 11 ).

## Fading in patches

Possible cause	Remedy
The paper is moist.	Store paper within specified temperature and humidity levels (see page 152).

## Longitudinal black stripes

Possible cause	Remedy
Image drum is damaged.	Replace image drum (see page 94).
Toner is low.	Change toner cartridge (see page 87).
Periodic black lateral lines or spots.	<ul style="list-style-type: none"><li>• If the lines or spots occur at intervals of approximately 44 to 94 mm, the green surface of the image drum is damaged or dirty. If damaged, replace the image drum cartridge (see page 94). If dirty, wipe the image drum gently with soft tissue. If this does not work, replace the image drum (see page 94).</li><li>• If the lines or spots occur at intervals of approximately 113 mm, the fuser roller is damaged. Change the fuser (see page 108).</li></ul>
The image drum has been exposed to light.	Remove the image drum from the printer and store it in a dark place for several hours. If this does not work, replace the image drum (see page 94).



## Faint shading on unprinted sections

Possible cause	Remedy
Paper has been affected by static electricity.	Store paper within specified temperature and humidity levels (see “Specifications” on page 152).
Paper is too thick.	Use recommended paper (see “Media Weight Designations” on page 11).
Toner is low.	Replace toner cartridge (see “Toner Cartridge Replacement” on page 87).

## Blurred letter edges

Possible cause	Remedy
LED is dirty.	Clean LED with lens cleaner or soft tissue.
Cannot print desired color because toner is low.	Replace toner cartridge (see “Toner Cartridge Replacement” on page 87).

## One side of printed pages appears blurred

Possible cause	Remedy
Top cover is not properly closed.	Press the cover release latch and open, then close, the cover.
One or more of the toner cartridges is not seated properly.	Open the top cover and check to be sure that each toner cartridge is fully seated and that each toner cartridge lock lever is pushed all the way back.

## MISCELLANEOUS PROBLEMS

### The power is on, but the printer does not go online.

Possible cause	Remedy
Bad connection	Switch off the printer and disconnect the power cable. Reconnect the power cable and switch the printer on. If this does not clear the fault, call for service.

### Print processing does not start.

Possible cause	Remedy
Printer error	Check the control panel. If an error message is displayed, correct the problem.

### Print processing cancels.

Possible cause	Remedy
The printer interface cable is faulty.	Replace the printer interface cable.
The time out setting is too short.	Reset time out in the menu to a higher value ( <b>SYS CONFIG MENU</b> → <b>WAIT TIMEOUT</b> ).

### Printer makes a strange noise.

Possible cause	Remedy
The printer is not horizontal.	Place the printer on a stable, level surface.
There are scraps of paper or other foreign matter inside the printer.	Check the inside of the printer and remove any such objects.
The top cover is not firmly shut.	Press the left and right sides of the top cover.

## Printer takes a long time to start printing.

Possible cause	Remedy
The printer has to warm up returning from power save mode.	In the printer menu settings, set power save to a higher value to increase the length of time before entering power save mode ( <b>SYS CONFIG MENU</b> → <b>POW SAVE TIME</b> ).
The image drum carries out a cleaning process to ensure print quality, which takes time.	Wait until this process has been completed.
The fuser unit adjusts temperature, which takes time.	Wait until this process has been completed.
The printer is processing data from another interface.	Wait until this data is processed.

## Toner rubs off when you rub the printed surface.

Possible cause	Remedy
Media Weight and Media Type settings may not be appropriate.	Set the value of media weight in the menu to the next heaviest one ( <b>MEDIA MENU</b> → <b>YYY MEDIA WEIGHT</b> ).
Packing materials were left on the fuser when it was installed.	<b>Careful!</b> Fuser may be <b>HOT!</b> Open the top cover and check to be sure that all the packing materials were removed from the fuser. To remove the fuser see "Changing the fuser unit" on page 355.

# Specifications

Item	Specification
Dimensions	16.61" W x 22.09" D x 13.58" H (422 mm W x 561 mm D x 345 mm H)
Net Weight	57.3 lbs. (26 Kg)
Print speeds	12 pages per minute (ppm) color 20 ppm monochrome <i>For Transparencies:</i> 5 ppm color, 12 ppm monochrome
Resolution	600 dpi or 600 x 1200 dpi
Emulation	Hiper-C
Environmental	<b>Temperature</b> <ul style="list-style-type: none"> <li>• Operating: 50 to 90°F (10 to 32°C)</li> <li>• Storage (packed up): -14 to 110°F (-10 to 43 °C)</li> <li>• Power Off: 32 to 110°F (0 to 43°C)</li> </ul> <b>Relative Humidity</b> <ul style="list-style-type: none"> <li>• Operating: 20 to 80% RH</li> <li>• Storage (packed up): 10 to 90% RH</li> <li>• Power Off: 10 to 90% RH</li> </ul>
Auto Features	Auto registration Auto density adjustment Auto consumable counter reset
Memory	32 MB standard, upgradable to 96 MB, 160 MB or 288 MB (see "RAM Memory" on page 113)
Paper capacity (20-lb. [75 g/m <sup>2</sup> ] paper)	Tray 1: 300 sheets Optional Tray 2: 530 sheets Multi-Purpose Tray: 100 sheets
Paper weight Range	Tray 1: 17 to 32 lb. (64 to 120 g/m <sup>2</sup> ) Optional Tray 2: 17 to 47 lb. (64 to 177 g/m <sup>2</sup> ) Multi-Purpose Tray: 20 to 54 lb. (75 to 203 g/m <sup>2</sup> )
Paper output	<b>Top Exit (Face Down Stacker):</b> 250 sheets 20-lb. 75 g/m <sup>2</sup> paper <b>Rear Exit (Face Up Stacker):</b> 100 sheets 20-lb. 75 g/m <sup>2</sup>
Printer life	420,000 pages or 5 years, whichever comes first

Item	Specification
Duty cycle	<i>Maximum:</i> 50,000 pages per month at 5% duty cycle (equivalent to an average business letter) <i>Average:</i> 4,000 pages per month
Toner life	5,000 pages at 5% coverage
Image drum life	15,000 pages at 3 pages per job
Belt life	50,000 letter-size pages
Fuser life	45,000 letter-size pages

# Utility Programs

## OVERVIEW

Included with your printer is a selection of software utility programs designed to help you get the most out of your printer. These programs are located on the driver CD supplied with your printer.

Utilities included:

- **Color Utility**
  - Color Swatch (see page 154)
- **Network Utilities**
  - PrintSuperVision (see page 157)
  - Network Printer Status (see page 158)
  - Oki LPR Utility (see page 161)

## COLOR SWATCH UTILITY

### General Information

The Color Swatch Utility allows you to print swatches of color samples on your Oki color printer. The swatches are used with your software program to select and reproduce color accurately. The swatches represent selected samples of the Oki color printer's color palette and provide corresponding RGB values which can be used to set up the desired colors for your printed documents.

### NOTE

- **Your software may not be able to match colors using the swatch information. You may need to use other matching methods.**
- **The color swatch samples do not show all the colors your Oki color printer can print.**
- **Other factors influence how you see color: the color and finish of the paper, ambient light, even the color surrounding the one you are looking at.**

## installing the Color Swatch Utility

1. Place the driver CD supplied with your printer in your CD-ROM drive and wait for the Menu Installer to open.  
(If the CD does not AutoPlay, click **Start** → **Run** → **Browse**. Browse to your CD-ROM and double-click **Install.exe**, then click **OK**.)
2. Click **Next** to accept the terms in the license agreement.
3. Click **Productivity Software** → **Color Swatch Utility** and follow the on-screen instructions.


## Opening the Color Swatch utility

Click **Start** → **Programs** → **Color Swatch** → **Color Swatch Utility**.

## Using the Color Swatch Utility

### Selecting Colors

When you load the utility, a swatch page displays commonly used colors. Select print to print sample pages.



### Color Samples

Use the color blocks to pick the specific colors that you want to appear in your printed document.

### Color Values

Each color block, or sample, is identified with information your software package needs to reproduce that color accurately. The numbers under each block specify the amounts of the primary colors—red (R), green (G), and blue (B)—that mix to form each

particular shade. The amounts are given as a numerical value between 0 and 255.

## Creating Custom Swatch Colors

If you don't find your desired color, you can create or customize colors:

1. Select **Custom Swatch** from the **File** menu.
2. On the pop-up window, there are 3 slide bars that allow you to customize swatches:
  - **Hue** bar changes the hue of the swatches, for example, red to green or blue to yellow.
  - **Saturation** bar changes vividness.
  - **Lightness** bar changes darkness.
3. Adjust the bars until you see the desired color. Color variations are created to help you find the best match.
4. Click **OK**, then print the custom swatch page.
5. Repeat these steps if you still don't find the desired printed color.

### NOTE

- **The Color Swatch Utility does not guarantee that the printer will print the same color displayed on your monitor. Consider the displayed color as a reference.**
- **The printer may not be able to print the exact color that you desire.**

For additional information, including **Applying Color Value in your Application**, and **Setting Monitor Color**, see the Color Swatch Utility Read-me file located in the Windows Programs list.



# PRINTSUPERVISION UTILITY

## General Information

PrintSuperVision is a web-based application for managing printing devices connected to a network. PrintSuperVision provides access to networked printer data for monitoring, reporting and managing networked printers. It provides a full range of management functions for Oki printers, and for other brands of printers as well.

## installing PrintSuperVision

1. Place the driver CD supplied with your printer in your CD-ROM drive and wait for the Menu Installer to open.  
*(If the CD does not AutoPlay, click Start → Run → Browse. Browse to your CD-ROM and double-click Install.exe, then click OK.)*
2. Click **Next** to accept the terms in the license agreement.
3. Click **Network Software** → **Administration Tools** → **PrintSuperVision** and follow the on-screen instructions.

## Features

- Provides real-time status of all your printers to monitor and report printer usage, manage consumables usage and replenishment.
- Interfaces to the system via a standard web browser enabling you to check on printer status and compatible multi-function devices from anywhere on the web.
- Performs initial discovery and configuration of printing devices connected to network.
- Lets you view groups of printers by list, floorplan or maps.
- Monitors devices over time, including maintenance data, and saves data for statistical reports.
- Sends mail alerts of events affecting device functionality.
- Generates reports on-screen or in XHTML, Excel, XML, Text, and CSV formats.
- Integrates with Oki Data's on-line web support.

## Additional Information

For more information:

- See your on-line OkiLAN® 8100 User's Guide (on the Drivers CD supplied with your printer)

**or**

- Click on **Help** in the PrintSuperVision program.

## NETWORK PRINTER STATUS UTILITY

This utility creates an additional tab (STATUS) in the printer driver that allows the client to monitor the selected printer's status.

### installing The Network Printer Status Utility Manually


If you are using Windows Plug-and-Play Add Printer Wizard to install the driver, here is how to install the Network Printer Status Utility:

1. Place the driver CD supplied with your printer in your CD-ROM drive and wait for the Menu Installer to open.  
*(If the CD does not AutoPlay, click Start → Run → Browse. Browse to your CD-ROM and double-click Install.exe, then click OK.)*
2. Click **Next** to accept the terms in the license agreement.
3. Click **Network Software** → **Administration Tools** → **Network Printer Status** and follow the on-screen instructions.

### To Open The Network Printer Status Utility

1. Click **Start** → **Settings** → **Printers**. Right-click the Printer icon, click **Properties**.
2. Click on the **STATUS** tab.

3. Click **UPDATE** to see the device settings. The following screen displays:



Click on an item to see this information:

Trays:	Paper Type, weight, size
Duplex:	Installed/not installed
Disk/Memory:	RAM size and % used; Flash Memory size and % used
Toner Remaining:	% toner remaining is shown for each cartridge.


## NOTE

If the Automatic Status Check box is checked, this utility will “ping” the printer each time you open the Printer Properties dialog in the printer driver. This will severely slow down the opening of this dialog.

To save time, click **Update** to refresh the display.

## Checking the Printer Status

Click the WEB SETTING button. The following screen displays:



Click on the items listed on the left to see:

- Network Summary
- Login for Administrators
- Job Login
- Printer Menu

To see real-time printer status, click the **UPDATE STATUS** button.

# OKI LPR UTILITY

The LPR Utility allows you to print directly to a printer on the network without a print server. It creates an Oki Printer Port, and installs a pop-up status box so you can monitor printer status.

LPR operates in Windows Me/98/95, Windows NT 4.0, Windows 2000, and Windows XP operating systems.


## How to Install

The LPR Utility supports TCP/IP. Your network administrator will first need to set up an IP address and TCP/IP properties for your printer.

Your network administrator may have already installed this software. If you need to install it manually:

1. Place the driver CD supplied with your printer in your CD-ROM drive and wait for the Menu Installer to open.  
*(If the CD does not AutoPlay, click Start → Run → Browse. Browse to your CD-ROM and double-click Install.exe, then click OK.)*
2. Click **Next** to accept the terms in the license agreement.
3. Click **Network Software** → **Administration Tools** → **OKI LPR** and follow the on-screen instructions.

## LPR Status box



The LPR Utility Status Box displays the following information:

- **Printers:** Names of added printers (You can add up to 30 printers)
- **Status:** LPR Utility status (empty, connecting, sending, paused, checking status, not connected)
- **Finish:** Number of completed jobs.
- **Queue:** Number of jobs waiting to be printed.

## **Additional Information**

For help using the LPR Utility, click on **HELP** in the program.